




4-Port USB 2.0 Extender over LAN Quick Start Guide

Before you get started, ensure that all the drivers required for your USB device(s) are installed.

Network Connect

- 1 Place the Local Extender where desired and connect the CAT5e/6/7 patch cable from the Link port (RJ-45) to a network switch or wall network port connected to a switch.



Maximum 330 ft. (100 m)
between devices

- 2 Connect the Local Extender to the computer using the included USB cable.



- 3 Place the Remote Extender where desired. Connect the CAT5e/6/7 patch cable from the Link port (RJ-45) to a network switch or wall network port connected to a switch and connect the Remote Extender to a power source.



Maximum 330 ft. (100 m)
between network devices

- 4 Attach the USB device(s) to the Remote Extender.




Contact Information

Order toll-free in the U.S. or for FREE 24/7 technical support: Call 877-877-BBOX
(outside U.S. call 724-746-5500)
www.blackbox.com • info@blackbox.com

Direct Connect

- 1 Place the extenders where desired and connect the CAT5e/6/7 extension link cabling to the Link ports (RJ-45) on the Local and Remote Extenders.



- 2 Connect the Local Extender to the computer using the included USB cable.



- 3 Connect the Remote Extender to the AC adapter and a power source.



- 4 Attach the USB device(s) to the Remote Extender.



FCC Radio Frequency Interference Statement Warning: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

CE Statement: Black Box declares under our sole responsibility that this product, to which this declaration relates, is in conformity with European Standard EN 55022, EN 61000 and EN 55024.

IC Statement: This Class B digital apparatus complies with Canadian ICES-003.

WEEE Statement: The European Union has established regulations for the collection and recycling of all waste electrical and electronic equipment (WEEE). Implementation of WEEE regulations may vary slightly by individual EU member states. Please check with your local and state government guidelines for safe disposal and recycling or contact your national WEEE recycling agency for more information.

Product Operation and Storage: Please read and follow all instructions provided with this product, and operate for intended use only. Do not attempt to open the product casing as this may cause damage and will void warranty. Use only the power supply provided with this product. When not in use, product should be stored in a dry location between -20°C and 70°C.

The full user manual/installation guide can be downloaded from the Black Box Web site. Go to www.blackbox.com, enter the part number (IC408A-R2) in the search box, click on the product in the "Product Results" page, then click on the "Support" tab on the product page, and select the document you wish to download.

© Copyright 2016, Black Box Corporation. All rights reserved. Printed in U.S.A. Black Box® and the Double Diamond logo are registered trademarks of BB Technologies, Inc. Any third-party trademarks appearing in this manual are acknowledged to be the property of their respective owners.

IC408A-R2 Quick Start Guide, version 2

FREE, live, 24/7 Tech Support is just 60 seconds away.
877-877-2269 | blackbox.com